



Proper way to set excess brake line on reserve risers



Improper way to set excess brake line on reserve risers

