

## Semi-Stowless Bag Instructions

1. Pack your canopy per manufacturer's instructions



Fig. 1 - Canopy laying flat in cocoon shown with RDS.

2. Place canopy in bag.



3. Stow RDS lanyard into pocket as applicable



Fig. 3 - RDS line coiled, and placed in pocket (if used, ignore if not on canopy)

4. Close top flap and thread rubber band through grommets to close bag. Stow lines as needed to keep top flap closed tightly, double wraps on rubber bands may be required.



Fig. 4 - Bag resting on end with both locking stows complete.

5. With the bottom of the bag resting flat on the ground lay the line flap out flat with flap facing towards rig.



6. Route lines from locking stows over the top of the bag and to base of flap.



## Semi-Stowless Bag Instructions

7. Begin figure eight line placement, stacking each placement upon the previous while pulling the rig towards you.



8. Ensure that line placement is done with each stow concentrically smaller.



9. Stow all lines up to end of lines (not past risers)



Fig. 9 – Stowed lines. Ensure that stowed lines do not exceed the width of the bag.

10. Pivot bag towards rig and lays it upon the coiled lines.



11. Laying bag flat on top of the lines place side tuck tabs (two tabs) in place.



Stow both left and right tabs.

12. Stand bag upright and close top flap tuck tabs (two flaps) making sure not to push lines into tab pocket.



13. Complete closing of container per man. recommendations.

